

Section I – Names of Parts	PAGE
Names of Parts	1
Names of parts	1
Standard Accessories	2
Large Extension Table	2
Extension Table	3
Stitch Chart	3
Section II – Getting Ready to Sew	4
Connecting the power supply	4
Speed Control Slider	5
Controlling Sewing Speed	5
Machine Operating Buttons	6
Start/Stop	6
Reverse Stitch	6
Auto Lock	6
Any Other Stitches	6
Needle Up/Down	7
Thread Cutter	7
Twin Needle	7
Touch Panel	8
Mode key	8
Clear key	8
Flip key	8
Memory key	8
Number keys	8
Stitch Width Adjustment	8
Cursor	8
LCD Display	8
Removing/Attaching Foot Holder	9
Changing Pressure Foot	9
Presser Foot Lifter	9
Presser Foot Pressure Dial	9
Dropping/Raising Feed Dog	10
Changing the Needle	11
Selecting Thread and Needles	11
Bobbin Winding	12
Horizontal Spool Pin	12
Additional Spool Pin	12
Winding the Bobbin	13
Inserting the Bobbin	14
Threading the Machine	15
Needle Threader	16
Drawing up the Bobbin Thread	17
Pattern Selection	18
Setting Mode	19
Buzzer sound setting	19
Needle Stop position setting	19
Key Position adjustment	19

Reset all to default	20
Adjusting the Needle Thread Tension	21
Correct tension	21
Tension is too tight	21
Tension is too loose	21
Adjust Needle Tension for Zigzag	22
Correct tension	22
Tension is too tight	22
Tension is too loose	22
Section III – Basic Sewing	23
Straight Stitch Sewing	23
Starting to sew	23
Finishing sewing	23
Turning square corners	23
Sewing from the edge of thick fabric	23
Needle Plate	24
Adjusting stitch length	24
Adjusting needle drop position	24
Straight Stitch	25
Lock-a-Matic Stitch	25
Locking Stitch	25
Triple Stretch Stitch	25
Stretch Stitch	26
Sculpture Stitch	26
New Sculpture Stitch	26
Zigzag Stitch	27
Adjusting the stitch width	27
Adjusting the stitch length	27
Multiple Zigzag	28
Overedge Stitch	28
Knit Stitch	29
Double Overedge Stitch	29
Zipper Sewing	30
Attaching the zipper foot	30
Fabric preparation	30
Start sewing	30
Blind Hemming	32
Adjusting the needle drop position	32
Bridge Stitch	33
Button Sewing	33
Attaching Elastic	34
Various Buttonholes and Their Uses	35
Square	35
Round-end	35
Fine Fabric	35
Keyhole	35
Stretch	35
Antique	35

Welled (Bound)	35
Square	36
Adjusting Stitch Width and Density	38
Adjusting stitch width	38
Adjusting stitch density	38
Round End Buttonhole	38
Fine Fabric Buttonhole	38
Keyhole Buttonhole	39
Stretch Buttonhole	39
Antique Buttonhole	39
Corded Buttonhole	40
Darning Stitch	41
Starting to sew	41
Sewing a shorter darning	41
Sewing a same-sized darning	41
Adjusting the evenness of the darning	41
Tacking	42
Start sewing	42
Sewing a shorter tacking	42
Sewing a same-sized tack	42
Eyelet	42
Starting to sew	42
Adjusting the shape of an eyelet	42
Section IV Decorative Stitching	43
Shelltuck Stitch	43
Applique	43
Adjusting the stitch width	43
Scallop Stitch	44
Smocking	44
Pintucking	44
Patchwork Piecing	45
Anglescale on needle plate	45
Stippling Stitch	45
Clasp Stitch	46
Fagoting	46
Satin Stitches	46
Fringing	47
Drawn Work	47
Cross Stitch	48
Decorative Stitches	48
Twin Needle Sewing	49
Starting to sew	49
Section V Programming Patterns and Letters	50
Programming the Auto-lock	50
Programming the Pattern Combination	51
Programming Auto-thread Cutting	51
Bridge Stitches	52

Janome 4120 QDC Table of Contents

To insert a space between patterns	52
Programming a Mirror Image	53
Sewing a Pattern Combination from Beginning	54
Sewing the Current Pattern from Beginning	54
Programming Letters	55
Reducing the Size of Letters	56
Viewing a Long Text	57
Deleting and Inserting a Letter (pattern)	57
Duplicating a Letter (pattern)	58
Stitch Adjustment of Programmed Patterns	59
Unified needle drop position	59
Correcting Distorted Stitch Patterns	61
Stretch stitch pattern	61
Stitch balance of buttonhole 26	61
Evenness of tacking	61
Section VI Care of Your Machine	62
Installing the Bobbin Holder	62
Problems and Warning Signs	63
Troubleshooting	64
Stitch Chart	65